

**Page Denied**

**SECRET**

0000780

25X1

59071/C-379

F

April 30, 1959

25X1

Subject: Contract No. RD-155 - Task Order No. 1

25X1

During the installation of the doors designed and fabricated under the subject Task Order, this contractor was requested to perform a number of additional items of work not provided for in the original proposal for accomplishing this program. A list of the more significant items is submitted with this letter as enclosure (A).

It is pointed out that this extra work was performed under field conditions at a site remote from our plant, and that the entire door installation program was on a "crash basis", both factors contributing substantially to the cost. Some overtime was worked in order to expedite completion of the program; however, since we did not obtain prior approval for such overtime, as required by the terms of the contract, we will not ask for reimbursement of the premium paid for such overtime work. Our costs for accomplishing the extra work described in enclosure (A) are as follows:

Estimated Cost . . . . .	\$7,234.45
Fixed Fee . . . . .	\$ 506.41
CPFF . . . . .	\$7,740.86

These costs do not include the cost of overtime premium which we will absorb.

We hope that an amendment to Task Order No. 1 can be issued promptly to cover the cost of performing this additional work.

25X1

TJH/jf

Encl. (A) List of Add'l Work Items

Copy:

**SECRET** 25X1

**SECRET**

ADDITIONAL WORK REQUESTED BY CUSTOMER DURING INSTALLATION OF DOORS - C-379.10

1. Move light into duct forward of door.
2. Plug ducts (ends).
3. Deactivate 1 micro-switch.
4. Relocate second micro-switch.
5. Move spotlights (2) to areas outside (fore & aft of) door area.
6. Add mechanism for emergency release of door operating mechanism.
7. Rebracket light on aft duct.
8. Add dust cover over mechanisms (both doors).
9. Prepare parts list for first door, listing:
  - a. A. N. Parts
  - b. Commercial parts
  - c. AAInc. parts
10. Reupholster inside of aircraft in door area after installing doors.
11. Remove anchor fittings for static lines.
12. Add new anchor fittings for static lines.
13. Add locking pin to bottom of aft door for safety.
14. Add stencilled letters for operating instructions and emergency instructions.
15. Buy cable, turnbuckles, and end fittings for static line.
16. Remove hinges from old door installation and add covers.
17. Add fairleads for electric cables.
18. Metal trim added to edges of doors to prevent air from getting under trim.

ENCLOSURE (A) TO LETTER 59071/C-379

**SECRET**